

NEMA Standards Publication

NEMA SB 10-2016

Audio Standard for Nurse Call Systems

National Electrical Manufacturers Association



NEMA Standards Publication SB 10-2016

Audio Standard for Nurse Call Systems

Published by:

National Electrical Manufacturers Association

1300 North 17th Street, Suite 900
Rosslyn, Virginia 22209

www.nema.org

© 2016 National Electrical Manufacturers Association. All rights, including translation into other languages, reserved under the Universal Copyright Convention, the Berne Convention for the Protection of Literary and Artistic Works, and the International and Pan American copyright conventions.

NOTICE AND DISCLAIMER

The information in this publication was considered technically sound by a consensus among persons engaged in its development at the time it was approved. Consensus does not necessarily mean there was unanimous agreement among every person participating in the development process.

The National Electrical Manufacturers Association (NEMA) standards and guideline publications, of which the document herein is one, are developed through a voluntary standards development process. This process brings together volunteers and/or seeks out the views of persons who have an interest in the topic covered by this publication. Although NEMA administers the process and establishes rules to promote fairness in the development of consensus, it does not write the documents, nor does it independently test, evaluate, or verify the accuracy or completeness of any information or the soundness of any judgments contained in its standards and guideline publications.

NEMA disclaims liability for any personal injury, property, or other damages of any nature, whether special, indirect, consequential, or compensatory, directly or indirectly resulting from the publication, use of, application, or reliance on this document. NEMA disclaims and makes no guaranty or warranty, express or implied, as to the accuracy or completeness of any information published herein, and disclaims and makes no warranty that the information in this document will fulfill any particular purpose(s) or need(s). NEMA does not undertake to guarantee the performance of any individual manufacturer's or seller's products or services by virtue of this standard or guide.

In publishing and making this document available, NEMA is not undertaking to render professional or other services for or on behalf of any person or entity, nor is NEMA undertaking to perform any duty owed by any person or entity to someone else. Anyone using this document should rely on his or her own independent judgment or, as appropriate, seek the advice of a competent professional in determining the exercise of reasonable care in any given circumstance. Information and other standards on the topic covered by this publication may be available from other sources, which the user may wish to consult for additional views or information not covered by this publication.

NEMA has no power, nor does it undertake to police or enforce compliance with the contents of this document. NEMA does not certify, test, or inspect products, designs, or installations for safety or health purposes. Any certification or other statement of compliance with any health- or safety-related information in this document shall not be attributable to NEMA and is solely the responsibility of the certifier or maker of the statement.

CONTENTS

	Page
Foreword	iii
Section 1 General	1
1.1 Scope	1
1.2 Purpose	1
1.3 Definitions	1
1.4 Referenced Publications	2
Section 2 General Requirements	3
2.1 Equipment Setup	3
2.2 System Output Levels	3
2.3 System Input Levels	3
2.4 Ambient SPL	3
2.5 Minimum Signal to Noise Ratio	3
Section 3 Test Equipment Required	8
Section 4 Test Procedure	10
4.1 Data Recording	11
4.1.1 Installation	11
4.1.2 Operation	11
4.2 NCS Output/Patient Station Input Sensitivity	11
4.2.1 System Configuration	11
4.2.2 Reference	11
4.2.3 Test	11
4.3 Mode A Signal to Noise (Patient Station)	11
4.3.1 System Configuration	11
4.3.2 Reference	11
4.3.3 Test Procedure	11
4.3.4 Calculations	11
4.4 Mode A Level (Pillow Speaker)	12
4.4.1 System Configuration	12
4.4.2 Reference	12
4.4.3 Test Procedure	12
4.5 NCS S/N from Pillow Speaker	12
4.5.1 System Configuration	12
4.5.2 Reference	12
4.5.3 Test Procedure	12
4.5.4 Calculations of Pillow Speaker S/N	12
4.6 Mode B Level (Patient Station)	12
4.6.1 System Configuration	12
4.6.2 Reference	13
4.6.3 Test Procedure	13
4.7 Mode B S/N (Patient Station)	13
4.7.1 System Configuration	13
4.7.2 Reference	13
4.7.3 Test Procedure	13
4.7.4 Mode B S/N (Patient Station)	13
4.8 Mode B Level (Pillow Speaker)	13
4.8.1 System Configuration	13
4.8.2 Reference	13

4.8.3	Test Procedure	13
4.9	Mode B S/N (Pillow Speaker)	14
4.9.1	System Configuration	14
4.9.2	Reference	14
4.9.3	Test Procedure	14
4.9.4	Calculation of the Mode B S/N (Pillow Speaker)	14

TABLES

Table 1	Nurse call audio performance data worksheet	10
---------	---	----

FIGURES

Figure 1	Setup for mode A level (NCS)	4
Figure 2	Setup mode B level, patient station/pillow speaker	5
Figure 3	Setup for mode B S/N ratio (pillow speaker/patient station)	6
Figure 4	Setup for mode A S/N ratio (NCS)	7
Figure 5	Test set: typical pillow speaker or patient station setup for S/N measurements	8
Figure 6	Test set: typical NCS setup for S/N measurements	9

FOREWORD

The preparation of this standard publication was initiated in response to input from the Veterans Administration. Input from other interested parties has also been sought and evaluated. Inquiries, comments and proposed or recommended revisions should be submitted to the concerned NEMA product subdivision at the following address:

Director, Technical Standards
National Electrical Manufacturers Association
1300 N. 17th Street, Suite 900
Rosslyn, VA 22209

NEMA standards publications are periodically reviewed to meet changing conditions and technical progress, and the latest edition shall be used. Comments from the users of NEMA SB 10-2016 are welcome, and should be sent to the above address.

By way of introduction, a nurse call system is used in healthcare facilities to provide audible tones and visual indications to alert staff of patient requests for help or assistance. Audio (voice) communication may be provided in addition to the primary audible and visual signaling indications to optimize and enhance staff response to patient requests for attention or assistance.

NFPA 99 *Health Care Facilities Code*, together with NFPA 70 *National Electrical Code*® and applicable state and local building codes, determines the requirements for nurse call systems in healthcare facilities. As of the 2015 edition of NFPA 99, the requirements for nurse call systems are codified. Most states typically rely on NFPA 99 and NFPA 70 to establish state and local requirements with little, if any, change.

ANSI/UL 1069 *Hospital Signaling and Nurse Call Equipment* provides detailed and specific construction, reliability, performance, and safety requirements for nurse call systems and associated equipment. It defines the fundamental equipment required and fundamental operations of a nurse call system, as well as the requirements for installation and user operation. Comprehensively, ANSI/UL 1069 is in conformance with the requirements set forth in NFPA 99 and NFPA 70. However, there is no standard that defines audio performance characteristics.

Therefore, this audio standard, NEMA SB 10-2016, is intended to be used by nurse call system manufacturers to claim conformity to a consensus audio standard, even though there is no third party NRTL assessment, certification, or requirement.

This NEMA standards publication is the result of many years of research and investigation by members of NEMA and some members of the ANSI/UL 1069 standards technical panel. It was developed through consultation among manufacturers, users, and testing laboratories, and it reflects the study of the standards and technical documents identified in section 1.4, which were helpful in its preparation.

NEMA SB 10-2016 is developed and maintained by the NEMA 3SB-2 Health Care Communications and Emergency Call Systems Group. Publication of this standard does not necessarily imply that all members of the 3SB-2 product group voted for approval or participated in its development.

At the time NEMA SB 10-2016 was approved, the 3SB-2 Health Care Communications and Emergency Call Systems Group consisted of the following members:

Aiphone Corporation
Ascom US Inc.
Cornell Communications, Inc.
Curbell Medical Products, Inc.
Heritage MedCall LLC
Inovonics

Rauland-Borg Corporation
Silversphere Technologies Inc.
SimplexGrinnell LP
Techtone Sound & Signal Mfg. Inc.
Tyco Fire Protection Product

<This page is intentionally left blank.>

Section 1 General

1.1 Scope

This publication contains the necessary requirements and test procedures to evaluate the audio quality of the loud speakers and microphones that may be provided in nurse control stations, patient stations, and pillow speakers of a UL listed nurse call system.

1.2 Purpose

This standard is intended to be used to evaluate the audio quality of a UL-listed nurse call system in an open-air installed system environment. It can also be used by manufacturers to establish pre-installation conformity with the requirements set forth herein.

1.3 Definitions

The following definitions apply to terms used in this standard.

intercom: The means by which two parties can communicate using the loud-speaking communications system, which may be integral to a listed nurse call system. For the purposes of this standard, the intercom is the actual circuitry that provides the audio communications capability. Also referred to as *audio communications*.

microphone: An electroacoustic transducer that converts acoustic energy to electrical energy. For the purpose of this standard, a loud speaker may operate as both a microphone and speaker.

mode A: A condition where the intercom is so configured that the nurse control station is “listening” to a patient via loud speaker, where the microphone is at the patient station or the pillow speaker.

mode B: A condition where the intercom is so configured that the nurse control station is “talking” to a patient via microphone, where the speaker is at the patient station or pillow speaker.

nurse control station (NCS): A required device of the nurse call system, which is intended to be permanently located at the nurses’ station to provide audible tones and visual annunciation of incoming call events. Typically, it also provides audio communication between the nurse and the patient. Many other features are optionally available. Also referred to as *nurse master station*.

patient station: A required device for a listed nurse call system, located on the wall behind the patient bed to allow patients or staff to summon help. It is typically activated by a call cord or pillow speaker and is required to be equipped with a call assurance indicator, which activates whenever a call event is placed. Also required is a reset switch for call cancelation. Typically, this device includes intercom circuitry for communications between patients and staff and circuits for television, entertainment, and environmental control.

pillow speaker: A required device for a listed nurse call system, sometimes called a pendant control, which may also provide intercom circuitry for communications between patients and staff and additional features such as speaker volume control, personal entertainment controls, and lighting controls.

pink noise: A random noise that is band-limited at 12 dB per octave, 20 Hz to 20 kHz equal energy per octave.

signal to noise ratio (S/N): The calculated ratio of the measured rms electrical value taken at the speaker when generating the minimum rated acoustic output level divided by the measured rms electrical value at the speaker when the microphone has been replaced with an equivalent resistive load.